


RSA for left hinged external opening door or left hinged internal or external opening gate

Gate and Door Benefits

- · Solution to exposed padlocks on any door or gate
- · Restrict attacks on shackle, hasp, staple and long throw locks.
- Reduces risk to break-ins from crow bar, pipe wrench and lock picking.
- · Restricts access to shackle or hook from a cordless angle grinder
- · Increasing your time to react to possible attacks.
- Reduce the cost of replacing padlock or stolen goods.
- · Save the time and inconvenience of claims.
- · Weather Protective cover
- Protects your padlock during snow and rain to prevent seizing or rusting.
- Helps to increase life span of padlock hasp and staple saving you money.
- · Hook anti lift plate
- · Restrict gate lifting or removal to help prevent fly tipping.
- Maintenance of sagging gate is negligible when supported on both hooks.
- Robust visible barrier to prevent opportunist attacks to main property.







LSA for right hinged external opening door or right hinged internal or external opening gate

4TRESS4GATES®

PADLOCK, SHACKLE, HASP & STAPLE COVER

Fitting Video



ADJUSTABLE HOOK & BAND COVER


Tel: 07847 511 968

Email:sales@4tress4gates.com


https://www.4tress4gates.com

Required Fittings

- 2 x M10 Coach bolts
- 2 x M10 nuts "if fitting cover plate to a door"
- 2 x Anti tamper shear nuts "if fitting cover plate to a gate"
- 1 x Hasp & staple "max width 75 mm"
- 1 x Padlock "Disc & container padlock types recommended"
- 1 x 19 mm Adjustable hook and band



MK7-T PADLOCK, HASP & STAPLE COVER




FOR 19 MM ADJUSTABLE HOOKS

Cover plate for 19 mm adjustable hook and band hangers used on timber external opening doors or internal / external opening gates.

Included in your MK7-T kit

One of either!



1 x Mk7-T Right side anti lift R "for left hinged external opening door or left hinged internal or external opening gate"



fitting product for use as a padlock hasp and staple cover plate

- Position cover plate central between hasp and staple on the door or gate with front flange edge flush with edge of door or gate
- Mark the positions of the 2×10 mm squared holes \mathbf{D} from the left and right flanges of the cover plate onto the door or gate.
- Drill 2 x 10 mm holes and insert 2 x M10 coach bolts through the 2 x 10 mm squared holes on cover plate D
- Inside the room secure with 2 x M10 bolts. "See photo 1A"



Fitting Video



fitting product for use as a adjustable hook & band cover plate

- Position cover plate central between the adjustable band.
- Slide cover plate so that anti lift plate A reaches the furthest point of the main support block S which supports the hook H to the flat mounting plate.
- If possible leave a 10-20 mm gap between the bottom of the hook S and top of anti lift plate A "See photos front page F"
- Mark the positions of the 2 x 10 mm squared holes from the left and right flanges
 of the cover plate onto the gate or door.
- Drill 2 x 10 mm holes and push through 2 x M10 coach bolts through the cover plates 2 x 10 mm squared holes D.
- Secure with 2 x M10 anti tamper shear nuts on the other side of the gate or 2 x M10 nuts on door installations.